



Introduction

Congratulations on choosing to buy a Tevion product. By doing so you now have the assurance and peace of mind that comes with purchasing a product made by one of Europe's leading manufacturers. All products brought to you by Tevion are manufactured to the highest standards of performance and safety, and, as part of our philosophy of customer service and satisfaction are backed by our comprehensive 3 year Warranty. We hope you will enjoy your purchase for many years to come.

Accessories

IR Sensor



Remote Control



Connecting Your HDMI Switcher

Connect the Switch Box to your TV via the output socket using a HDMI cable



Attaching Your IR Sensor

Connect the IR sensor to the IR socket on the Switch Box and place the sensor on a flat surface with no obstructions between the sensor and the remote control.



3 WAY HDMI SWITCH BOX

User Guide

Model Number - 43779

Attaching Your HDMI Cables

Attach your chosen device to the Switch Box using a HDMI cable via one of the three input sockets on the Switch Box. As soon as the power supply of your chosen device is connected the switcher will respond automatically with a red LED light.



Select Your Chosen Device

You can switch between your devices via the remote control by selecting the input number of your chosen device, or via the 'select' button on the switcher. When pressing this you will notice the red LED light switch between each input 1,2 or 3. The LED will default to position 1 until you use the additional HD inputs.



Battery Disposal and Safety Information



The remote control supplied with this product contains a CR type battery. Do not dispose of batteries in your household waste. Please contact your local authority for details on safe disposal.

- Never throw batteries into a fire or expose to excessive heat sources.
- If batteries are swallowed, please seek immediate medical attention.
- Always ensure correct +/- polarity when installing batteries.
- Do not recharge non rechargeable batteries.



Electrical and electronic equipment (EEE) contains materials, parts and substances, which can be dangerous to the environment and harmful to human health if waste of electrical and electronic equipment (WEEE) is not disposed of correctly.

Equipment, which is marked with the WEEE logo (as shown on the left), should not be thrown away with your household waste. Contact your Local Authority Waste Disposal Department, as they will be able to provide details of the recycling options available in your area.