



DAB and FM Radio

DAB Layout and Functions



Switching on your DAB Radio

On the back of the DAB radio you will find the DC IN socket and the battery compartment. You can power the unit with the supplied DC adaptor or 6 x AA batteries (not included).



Once you have connected the radio to a power source, extend the antenna fully to ensure you get the strongest reception possible. Turn the OFF/MAX button clockwise to switch the radio on. Once turned on, the radio will start to scan for stations. The OFF/MAX button also controls the volume. Turn the button anticlockwise to turn the radio off.

Note: When using batteries, always ensure that they are the correct polarity and the +/- are inserted the correct way.

For full instructions, please refer to the user guide.