



## Wireless Amp Speaker With AUX Port

**MODEL NUMBER: 73200**


**USER GUIDE**

### After Sales Support

UK/N.IRELAND HELPLINE N°: 01270 508538  
REP.IRELAND HELPLINE N°: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)



# Contents

1. Welcome Section
2. Information & Safety Instructions
3. Contents & Features
4. Controls & Layout
5. Operating
  - Using the /Mode Button
  - Mode Options
5. Bluetooth
  - Pairing
  - Pair To Another Device
  - Reconnecting
6. AUX IN
  - Using The AUX IN Port
6. Volume & EQ
  - Volume
  - EQ
7. Specifications  
FAO's

## After Sales Support

UK/N.IRELAND HELPLINE N°: 01270 508538

REP.IRELAND HELPLINE N°: 1800 995 036

WEBSITE: [www.quesh.co.uk](http://www.quesh.co.uk)

EMAIL: [enquiries@quesh.co.uk](mailto:enquiries@quesh.co.uk)

# Welcome Section

Congratulations!

You have made an excellent choice with the purchase of this quality MAXTEK® product.

By doing so you now have the assurance and peace of mind which comes from purchasing a product that has been manufactured to the highest standards of performance and safety, supported by the high quality standards of Qesh Ltd.

We want you to be completely satisfied with your purchase, so this MAXTEK® product is backed by a comprehensive manufacturer's 3 year warranty and outstanding after sales service through our dedicated helpline.

We hope you enjoy using this product for many years to come.

If you require technical support or in the unlikely event that your purchase is faulty, please telephone our helpline for immediate assistance. Faulty product claims made within the 3 year warranty period will be repaired or replaced free of charge provided that you have a satisfactory proof of purchase (keep your receipt safe). This does not affect your statutory rights. However be aware that the warranty will become null and void if the product is found to have been deliberately damaged, misused and/or disassembled.

## After Sales Support

UK/N.IRELAND HELPLINE N°: 01270 508538  
REP.IRELAND HELPLINE N°: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)



# General information & Safety Instructions

Please read the following safety information before use.



- To avoid risk of electric shock do not attempt to open this appliance.
- Keep away from fire.
- Do not expose the appliance or mains adaptor to water, rain or dampness.
- Keep this appliance away from direct sunlight and other heat sources.
- Keep this appliance away from strong magnets.
- Never cover the ventilation slots on the underside or back of the appliance.
- Avoid placing heavy objects on top of the appliance.
- Always disconnect the appliance from mains power before cleaning.
- Clean the exterior of the appliance with a soft cloth only.
- The instructions for use shall state that the appliance shall not be exposed to dripping or splashing and that no objects filled with liquids such as vases, cups, etc, shall be placed on the appliance.
- Where the MAINS plug or appliance coupler is used the device shall remain readily operable.
- Where an all-pole MAINS SWITCH is used as the disconnection device, the function of the switch shall remain readily operable.
- This product should be used under direct adult supervision.  
Children should be supervised to ensure they do not play with this product.

**NEVER LEAVE CHILDREN UNATTENDED WITH ELECTRICAL EQUIPMENT**

#### After Sales Support

UK/N.IRELAND HELPLINE N<sup>o</sup>: 01270 508538  
REP.IRELAND HELPLINE N<sup>o</sup>: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)

# Contents & Features

## Contents

- 1 x Wireless Amp Speaker
- 1 x 12V Mains Adaptor

## Features

- 2x 12W Stereo speakers
- Bluetooth Ver. 4.0
- 10m Bluetooth range
- 3.5mm AUX IN port
- Bass control
- Treble control

## Adaptor Care


To get the best out of your adaptor please observe the following:

- Always remove the adaptor by holding the body of the plug or by holding the connector's body and not the wire.
- Do not wrap the cable around the body of the adaptor. This can cause harm to the cable. Instead bunch the cable up as it was presented in the package.
- Always secure any loose trailing cable to avoid accidents.

### After Sales Support

UK/N.IRELAND HELPLINE N<sup>o</sup>: 01270 508538  
REP.IRELAND HELPLINE N<sup>o</sup>: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)

# Controls & Layout



## After Sales Support

UK/N.IRELAND HELPLINE N<sup>o</sup>: 01270 508538

REP.IRELAND HELPLINE N<sup>o</sup>: 1800 995 036

WEBSITE:


[www.qesh.co.uk](http://www.qesh.co.uk)

EMAIL:


[enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)

# Operating

## Using the /Mode Button

Once you have connected the adaptor to a suitable mains supply and the back of the speaker, press the /Mode button to turn the speaker on. To turn the speaker off press and hold the same button for a few seconds till the speaker turns off.

## Mode Options

When the speaker is turned on you can choose between the Bluetooth input and AUX input for your audio source by pressing the /Mode button. The blue LED indicates that the speaker is in bluetooth mode and the red LED indicates that the speaker is in AUX IN mode

# Bluetooth

## Pairing

Once the speaker is turned on it will automatically search for a device to pair with. Search with your device for 'MAXTEK AUDIO' and select it to pair. There is no security code so the speaker should pair automatically once you've selected it.

## Pair To Another Device

Press the 'PAIR' button to disconnect the current connected device and allow another device to pair with the speaker.

## Reconnecting


The speaker will automatically attempt to connect to the last device it was paired with. If it doesn't find the device the speaker will move on to searching for another device to pair with.

### After Sales Support

UK/N.IRELAND HELPLINE N<sup>o</sup>: 01270 508538  
REP.IRELAND HELPLINE N<sup>o</sup>: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)

# AUX IN

## Using the AUX IN port

You can connect a device to the speaker using a 3.5mm audio/AUX cable (not supplied). Press the /mode so that the red LED lights up to indicate the AUX IN is the primary audio source.

### *Please Note:*

If you are connecting a phone, MP3 player, laptop, etc use the headphone socket to connect the audio/AUX cable to the AUX IN port on the speaker.

# Volume & EQ

## Volume

Turn the volume dial clockwise to raise the volume or counter clockwise to lower the volume.

## EQ

Turn either the Bass or Treble dial clockwise or counter clockwise to adjust the sound frequency bias of the audio output.

### After Sales Support

UK/N.IRELAND HELPLINE N<sup>o</sup>: 01270 508538

REP.IRELAND HELPLINE N<sup>o</sup>: 1800 995 036

WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)

EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)



# Specifications

## Wireless Amp Speaker


Bluetooth: Ver. 4  
Bluetooth Protocol: AD2P  
Bluetooth Range: Approx. 10m  
Power Requirement: 12V/2A  
Audio Type: Stereo  
Speakers: 2 x 12W  
AUX IN Port: 3.5mm  
Weight: 2.0Kg Approx.  
Dimensions: 265mm x 140mm x 150mm

## FAQ's

Problem	Cause	Solution
Bluetooth dropping out after a few minutes.	Full device cache on device.  Connected device has low power.	Manually clear the device's cache & restart the device.  Recharge the connected device or connect it to a power source.
Stuttering/delay music.	Too many processes running on device.  Corrupt bluetooth profile.  Interference.	Close unused apps.  Unpair & delete bluetooth profile, then re-pair device.  Use away from high powered devices or strong RF signals.
No music	No compatible music app.  A2DP is not available on your device.  Speaker not paired.  No power.  Volume low.	Use a compatible music app.  None.  Check bluetooth is on & the device is connected.  Turn on Speaker.  Turn the volume up.

### After Sales Support

UK/N.IRELAND HELPLINE N°: 01270 508538  
REP.IRELAND HELPLINE N°: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)



# Warranty Certificate

---

## Warranty

This product is warranted to be free from defects in workmanship and parts for a period of 36 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product the consumer has under existing U.K. laws.

## Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase receipt as proof of purchase and as proof of the date of when the purchase was made. The receipt must be presented with the warranty card when making a claim under this warranty.

## Service during the Warranty Period

Please ensure the product is properly packaged so as to ensure that no damage occurs in transit. Also make sure that you have included a detailed explanation of the problem.

## Extent of the Warranty

This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not extend to accessories.

## Normal Wear and Tear

This warranty does not cover normal wear and tear of the product or parts.

## Exclusions

This warranty does not cover the following:

- Any defect caused by accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has been damaged by lightning strike either directly or indirectly, or on a main's or vehicle outlet power surge or liquid ingress.
- Any product that has not been installed, operated or maintained in accordance with the manufacturer's operating instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- The product if it is located outside of the U.K. and Ireland
- Any damage caused by improper power input or improper cable connection.

Your statutory rights are not affected.

---

## After Sales Support

UK/N.IRELAND HELPLINE N°: 01270 508538  
REP.IRELAND HELPLINE N°: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)





# Warranty Card

## Wireless Amp Speaker with AUX port

**Model Number: 73200**

Please keep your purchase receipt together with your warranty card

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

 \_\_\_\_\_

Date of purchase: \_\_\_\_\_

Location of purchase: \_\_\_\_\_

**Fault Description:**

We recommend that you attach a photocopy of your receipt, showing the date of purchase, to this warranty card and keep it for your reference. In the event of a product fault, please call the After Sales Support team. Please ensure that you have the product details (as shown on this card) to hand so that the support team are able to respond as quickly and efficiently as possible.

**After Sales Support**

UK/N.IRELAND HELPLINE N<sup>o</sup>: 01270 508538  
REP.IRELAND HELPLINE N<sup>o</sup>: 1800 995 036  
WEBSITE: [www.qesh.co.uk](http://www.qesh.co.uk)  
EMAIL: [enquiries@qesh.co.uk](mailto:enquiries@qesh.co.uk)

**Service Helpline**

QESH LTD,  
B7, FIRST BUSINESS PARK  
FIRST AVENUE, CREWE, CHESHIRE.  
CW1 6BG



