

REKCI®

User Manual


WIRELESS HEADPHONES




Contents



Package contents	3
Components	6
General information	7
Reading and storing the user manual.....	7
Proper use.....	7
Explanation of symbols	8
Safety	8
Signal symbol/word definitions	8
General safety instructions.....	9
Checking the product and package contents	13
Charging	14
Putting on the product	14
Turning on or off	15
Pairing with a Bluetooth enabled device	15
Listening via Bluetooth connection	16
Hands-free functions.....	17
Listening via wired connection	17
Troubleshooting	18
Cleaning	19
Storage	20
Technical data	20
Declaration of conformity	21
Disposal	21
Disposing of the packaging	21
Disposing of the product.....	21

Package contents



Package contents





Components

- 1 Headband
- 2 Right ear cup
- 3 Left ear cup
- 4 Control button
- 5 **+>** button
- 6 AUX input jack
- 7 **<-** button
- 8 Charging port
- 9 LED indicator light
- 10 USB charging cable

Fig. D: Audio cable is not provided.

General information

Reading and storing the user manual



This user manual accompanies these wireless headphones (hereafter referred to as the “product”), and contains important information on setup and handling.

Before using the product, read the user manual carefully. This particularly applies to the safety instructions. Failure to do so may result in personal injury or damage to the product.

The user manual is based on the standards and rules in force in the European Union. When abroad, you must also observe country-specific guidelines and laws.

Store the user manual for further use. Make sure to include this user manual when passing the product on to third parties.

Proper use

The product is designed for audio playback from Bluetooth enabled playback devices. It is only intended for private use and not suitable for commercial purposes.

Only use the product as described in this user manual. Any other use is considered improper and may result in damage to property or persons. The product is not a children’s toy.

The manufacturer or vendor cannot be held liable for damages or injury incurred through improper or incorrect use.

Explanation of symbols

The following symbols and signal words are used in this user manual, on the product or on the packaging.



This symbol provides you with useful additional information on handling and use.



Declaration of Conformity (see chapter “Declaration of Conformity”): Products labelled with this symbol meet all applicable provisions of the European Economic Area.



Warranty period: 36 months

Safety

Signal symbol/word definitions

The following symbols and signal words are used in this user manual.



This signal symbol/word designates a hazard with moderate risk, which may result in death or severe injury if not avoided.

NOTICE!

This signal word warns of possible damage to property.

General safety instructions



Risk due to extreme volume!

Loud music can damage your hearing.

- Avoid listening at extreme volumes, particularly for prolonged periods of time when using the product. If you use the product at an excessively high volume, you could permanently damage your hearing.
- Listen at a moderate volume. As a guide to setting the volume level, check that you can still hear your own voice, when speaking normally while listening with the product.



Risk of injury!

Risk of impaired awareness!

- Audio warnings, alerts and environmental noises may sound different when wearing the product. Be aware of how

these signals differ in terms of their sound so that you are able to recognise the signals in corresponding situations.

- Do not use the product when driving motor vehicles, cycling, when operating machines or in other situations where impaired awareness of noises in your surroundings could pose a risk to you or others. At the same time, also observe the legal regulations and provisions in the country where you use the product.



Risk of injury!

Improper handling of the product may result in injury.

- The magnetic fields generated by the product could affect pacemakers and implanted defibrillators. Therefore, make sure there is a distance of at least 10 cm between the product and the pacemaker/defibrillator.
- Lay the USB charging cable so that it does not pose a tripping hazard.

- Children must not play with the product.
- Do not allow children to play with the packaging wrapper and do not pull small parts off of the product and put them in their mouth. There is a danger of suffocation.
- Do not use the product in environments where there is a risk of explosion.



Risk of explosion or chemical burns!

Improper handling of rechargeable battery may result in explosion or chemical burns.

- Do not heat the product. Keep the product away from hot surfaces.
- Do not throw the product into open fire.
- Protect the product from direct sunlight.
- Do not charge the rechargeable battery in the direct vicinity of hot surfaces or objects.
- Do not allow leaked battery acid to come into contact with skin, eyes or mucous membranes.

- In the event of contact with battery acid, immediately flush the applicable areas with plenty of clean water and consult a physician.

NOTICE!

Risk of damage!

Improper handling of the product may result in damage to the product.

- Do not perform any conversions or modifications to the product yourself.
- Check the product for visible external damage before you use it. Do not operate a damaged product.
- Do not immerse the product or the USB charging cable in water or other liquids.
- Never use the USB charging cable as a carrying handle.
- Never operate the product in wet rooms or in the rain.
- Protect the product against damage caused by (for examples):
 - dripping and splashing water,

- heat, direct sunlight and open flames (e.g. candles),
- shocks and similar impacting forces.
- Protect the USB charging cable against damage caused by (for examples):
 - sharp edges,
 - hot areas,
 - clamping or crushing.

Checking the product and package contents

NOTICE!

Risk of damage!

If you are not cautious when opening the packaging with a sharp knife or other pointed object, you may quickly damage the product.

- For this reason, be very careful when opening the packaging.
 1. Take the product out of the packaging.
 2. Check to make sure that all parts are included (see **Fig. A**).
 3. Check whether the product or individual parts are

damaged. If this is the case, do not use the product. Contact the manufacturer via the service address indicated on the warranty card.

Charging



- Fully charge the built-in rechargeable lithium battery of the product before use. It may take up to a few hours for a full charge.
- The LED indicator light **9** flashes red when the battery power is low. Recharge the product.

1. Connect the smaller connector of the USB charging cable **10** to the charging port **8** (see step 1 in **Fig. B**).
2. Connect the larger connector of the USB charging cable to a USB power supply (e.g. USB port of a computer) (see step 2 in **Fig. B**).

Charging of the product will start automatically. The LED indicator light will light up red to indicate that charging is in progress.

3. Once the product is fully charged, the LED indicator light will turn blue. Remove the USB charging cable from the charging port and the USB port.

Putting on the product

1. Make sure the sides are correct when you put on the product. The two ear cups (**2** and **3**) are marked with "R" (right) and "L" (left) on the inside of the headband **1** at where the ear cups fold inwards.

2. If necessary, adjust the headband length so that the product is comfortably positioned on your head and the ear cups firmly cover your ears (see **Fig. C**).

Turning on or off

- To turn the product on, press and hold the control button **4** until you hear the audio alert “Power on”.

The LED indicator light **9** flashes blue when the product is turned on.

- To turn the product off, press and hold the control button until you hear the audio alert “Power off”.

Pairing with a Bluetooth enabled device

1. Press and hold the control button **4** until you hear the audio alerts “Power on” and then “Ready to pair”.

The LED indicator light **9** flashes red and blue when the product is ready for pairing.

2. Turn on the Bluetooth feature of your Bluetooth enabled device and select “REKA AUDIO” from the list of available devices to pair.

When Bluetooth pairing is done, you hear a signal sound and the LED indicator light flashes blue.

The product is now ready for playback.



The product remembers your last paired device and automatically connects with it once the product is turned on. If you want to pair the product with a new device, repeat the steps above to clear the memory.

Listening via Bluetooth connection

1. Connect your Bluetooth enabled device with the product via Bluetooth connection (see chapter “Pairing with a Bluetooth enabled device”).
2. Start playback on your device.
3. Use the buttons on the right ear cup **2** to control the playback.

Button	Control
Control button 4	Press once to pause or resume playback.
+> button 5	Press once to increase the volume.
	Press and hold to skip forward.
← button 7	Press once to decrease the volume.
	Press and hold to skip backward.



During playback, the blue LED indicator light **9** flashes once every 5 seconds. When playback is paused, the blue LED indicator light flashes twice every 5 seconds.

Hands-free functions

If connected with a mobile phone via Bluetooth connection, you can receive calls and speak through the built-in microphone of the product. Refer to the table below for hands-free operations.

Control	Operation
Answer an incoming call	Press the control button 4 once.
End the call	Press the control button once.
Reject an incoming call	Press and hold the control button until you hear a signal sound.
Redial the previously called number	Press the control button twice.

Listening via wired connection

- You can also connect the product to an audio device through a 3.5 mm audio cable (not provided). To do so, connect one end of the audio cable to the AUX input jack **6** and the other end to the headphone jack of the audio device (see **Fig. D**).
- All playback controls must be made on the audio device.
- The Bluetooth function will automatically end once the product is connected with an audio cable. To use the product via Bluetooth connection again, disconnect the audio cable and then press and hold the control button **4** to turn the product on (see chapter “Turning on or off”).

Troubleshooting

Problem	Possible cause/solution
<p>Bluetooth pairing cannot be established.</p>	<p>Make sure the product is within its effective working range (10 m).</p> <p>If the product is connected to another Bluetooth enabled device, disconnect it first from the product and pair again.</p> <p>Make sure your Bluetooth enabled device's Bluetooth function is turned on and it is discoverable.</p> <p>If there are too many Bluetooth enabled devices near the product, turn off unused devices to avoid interference.</p>
<p>The sound is too soft.</p>	<p>Check the volume setting on both the product and the connected device, and adjust the volume to a suitable level.</p>
<p>Poor sound quality or distorted sound.</p>	<p>Make sure your Bluetooth enabled device is within the product's Bluetooth range. Move your device closer to the product.</p>

Cleaning

NOTICE!

Risk of short circuit!

Water or other liquids that have penetrated the housing may cause a short circuit.

- Make sure that no water or other liquids penetrate the housing.
- Never immerse the product in water or other liquids.

NOTICE!

Risk of damage!

Improper handling of the product may result in damage to the product.

- Do not use any aggressive cleaners, brushes with metal or nylon bristles, or sharp or metallic cleaning utensils such as knives, hard scrapers.
They could damage the surfaces.
- Use a damp cloth to wipe off the product. Then let all parts dry completely.

Storage

All parts must be completely dry before being stored.

- Always store the product in a clean and dry area.
- Protect the product from direct sunlight.
- To save space when transporting the product, fold the ear cups (**2** and **3**) inwards (see **Fig. E**).

Technical data

Model:	BOS-01
Transmitter output:	30 mW
Max. power:	50 mW
Drive unit:	40 mm
Impedance:	32 Ω
Sensitivity:	88 dB
Frequency range:	200 Hz-12 KHz
Rechargeable battery:	300 mAh lithium battery
Charging requirement:	5 V/300 mAh
Active use:	Up to 10 hours
Bluetooth:	Version 4.1
Bluetooth protocol:	AD2P, AVRCP, HSP, HFP
Weight:	175 g
Product code:	19072

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HANDS (IP) Holdings Pty Ltd is under license. Other trademarks and trade names are those of their respective owners.

Declaration of conformity



Hereby, Qesh Ltd declares that these wireless headphones are in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.qesh.co.uk

Disposal

Disposing of the packaging



Sort the packaging before you dispose of it. Dispose of paperboard and cardboard with the recycled paper service and wrappings with the appropriate collection service.

Disposing of the product

(Applicable in the European Union and other European countries with separate collection systems of recyclable materials)



Old appliances may not be disposed of in the household waste!

Should the product no longer be capable of being used at some point in time, **dispose of it in**

accordance with the regulations in force in your city or county. This ensures that old appliances are recycled in a professional manner and also rules out negative consequences for the environment. For this reason, electrical equipment is marked with the symbol shown here.

Batteries and rechargeable batteries may not be disposed of with household waste!



As the end user you are required by law to bring all batteries and rechargeable batteries, regardless whether they contain harmful substances* or not, to a collection point run by the city or county, or to a retailer, so that they can be disposed of in an environmentally friendly manner.

Bring the entire product (including the rechargeable battery) to your collection point and make sure that the battery is in an uncharged state!

*labelled with: Cd = cadmium, Hg = mercury, Pb = lead

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 3 years after date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product, please contact us via our helpline support services, details of which are to be found both in this manual and on the product itself.



PRODUCED IN CHINA FOR:

QESH LTD.
B7 FIRST BUSINESS PARK
FIRST AVENUE
CREWE
CHESHIRE
CW1 6BG
UNITED KINGDOM

AFTER SALES SUPPORT

19072



GB 01270508538

IE 1800 995 036



www.qesh.co.uk

MODEL:
BOS-01

08/2019

3
YEAR
WARRANTY